



Scan this code to get the most updated manual.

INSTALLATION, OPERATION & MAINTENANCE MANUAL



MODELS:

SDPL-8KMS 4-POST LIFT



FOLLOW THIS MANUAL CAREFULLY TO ENSURE THE EQUIPMENT WILL FUNCTION CORRECTLY AND PROVIDE MANY YEARS OF DEPENDABLE SERVICE. FAILURE TO FOLLOW THESE INSTRUCTIONS AND SAFETY WARNINGS MAY RESULT IN PERSONAL INJURY OR PROPERTY DAMAGE. KEEP THIS MANUAL IN A SAFE DRY PLACE FOR FUTURE REFERENCE.



**Products May Be
Upgraded Without Notice
Please Visit**

WWW.TITANLIFTS.COM

**For The Latest Version Of
This Manual**

CONTENTS

1-SAFETY	2
1.1 INTRODUCTION	2
1.2 SAFETY INSTRUCTIONS FOR COMMISSIONING	2
1.3 SAFETY INSTRUCTIONS FOR OPERATION	2
1.4 SAFETY INSTRUCTIONS FOR MAINTENANCE	4
1.5 RISKS	4
2-UNPACKING & SET-UP	5
2.1 DELIVERY AND CHECK OF PACKAGES	5
2.2 LIFTING AND HANDLING	5
3-SPECIFICATIONS	6
3.1 PARTS CHECK	9
4-FLOOR REQUIREMENTS	10
4.1 SELECTING THE SITE AREA	10
4.2 FLOOR REQUIREMENTS	10
4.3 ANCHORING TIP SHEET	11
5-INSTALLATION INSTRUCTIONS	12
5.1 COLUMNS AND CROSSBARS	12
5.2 RUNWAY INSTALLATION	14
5.3 CABLE INSTALLATION	15
5.4 HYDRAULIC ASSEMBLY	16
5.5 FINAL ADJUSTMENTS	17
6-OPERATION INSTRUCTIONS	18
6.1 DEFECTS / MALFUNCTIONS	18
6.2 CONTROLS	18
6.2.1 UP CONTROL	18
6.2.2 SAFETY LOCK CONTROL	18
6.2.3 LOWERING CONTROL	18
6.3.1 VEHICLE LOADING	19
6.3.2 RAISING THE LIFT	19
6.3.3 LOWERING THE LIFT	19
OPTIONAL CASTER KIT	20
7-MAINTENANCE	20
7.1 MAINTENANCE SCHEDULE	20
7.1.1 DAILY	21
7.1.2 WEEKLY	21
7.1.3 YEARLY	21
7.1.4 SPECIAL MAINTENANCE TASKS	21
7.2 MAINTENANCE BY OPERATOR	22
7.2.1 HYDRAULIC SYSTEM	22
7.2.2 GREASING POINTS	22
7.2.3 OPERATION AND WEAR CHECKS	22
7.2.4 LIFT STABILITY	22
7.3 CLEANING	23
8-TROUBLESHOOTING	23
9-DIAGRAMS/PARTS	25



TITAN MARKETING, LLC

PO Box 7069 Greenwood, IN 46142
1.888.908-4826 FAX (317) 215.2770
www.titanlifts.com

To Our Valued Customers:

Thank you for purchasing a Titan Lifts® product. We hope this high quality equipment provides you with years of dependable service.

It is unfortunate that rare situations may occur with the products you purchase from Titan Lifts®. We value your business as well as the trust you have and need to maintain your relationship with us. Titan Lifts® carries liability coverage that may protect our customers if a situation does occur. However, as in all accidents there must be proof of liability for a claim to be made. Our insurance company requires the following procedures be observed in order to consider a claim:

- A. The claimant must contact the Titan Lifts® distributor immediately with the facts of the situation.
- B. If any equipment is damaged, including vehicles or shop equipment, Titan Lifts® must be given the opportunity to send an impartial representative to the site for proper assessment of the situation.
- C. The Vehicle cannot be moved until either an impartial representative has reviewed the accident or clear and precise pictures are taken that reflect all the pertinent information for an impartial representative to be able to access the information from a distance. Titan Lifts® or its representatives must approve the pictures before anything can be moved.
- D. If any potential liability is determined on behalf of Titan Lifts®, two estimates must be submitted for damages to be reimbursed.

It is imperative that the claimant complies with these procedures, because without proper assessment of the situation a claim will be denied.

ARBITRATION NOTICE

The installation or use of this equipment shall constitute an acknowledgement that the user agrees to resolve any and all disputes or claims of any kind whatsoever, which relate in any way to the equipment, by way of binding arbitration, not litigation. No suit or legal action may be filed in any state or federal court. Any arbitration shall be governed by the Federal Arbitration Act, and administered by the American Mediation Association, Indianapolis Indiana. The maximum amount that an arbitrator may award and all damages shall not exceed the retail value of this equipment.

WARRANTY NOTICE

This equipment must be installed by a "Professional Installer" assembled and used in the manner according to the documentation provided to be covered by warranty.

Damaged or missing components must be reported within 72 hours of receipt to your freight carrier and to the distributor. Claims must be filed to cover cost.

If you have any questions or if we can be of any further assistance, please don't hesitate to contact a Titan Lifts® representative at 1-888-908-4826. Thank you for the opportunity to continue to serve your lift equipment needs.

INSTRUCTIONS

1-SAFETY

1.1 INTRODUCTION



WARNING: READ ENTIRE MANUAL AND COMPLY WITH ALL SAFETY AND SERVICE PRECAUTIONS. DEATH, PERSONAL INJURY AND / OR PROPERTY DAMAGE MAY OCCUR IF INSTRUCTIONS ARE NOT FOLLOWED CAREFULLY.

Personal injury and property damage incurred due to non-compliance with these safety instructions are not covered by the product liability regulations.

SYMBOLS



FAILURE TO COMPLY WITH INSTRUCTIONS COULD RESULT IN PERSONAL INJURY.



FAILURE TO COMPLY WITH INSTRUCTIONS COULD RESULT IN PROPERTY DAMAGE.



IMPORTANT INFORMATION

1.2 SAFETY INSTRUCTIONS FOR COMMISSIONING

- The lift may be installed and commissioned by authorized service personnel only.
- The standard lift version may not be installed and commissioned in the vicinity of explosives or flammable liquids, outdoors or in moist rooms (e.g. car wash).

1.3 SAFETY INSTRUCTIONS FOR OPERATION

- Read this entire manual.
- Load should not exceed rated capacity for this lift – 8,000 lb
- Only trained authorized personnel over the age of 18 years should operate the lift.
- Indoor use recommended.
- Never use the lift to raise one end or one side of vehicle.

- Maintain a safe working environment. The work area should be clean, dry, clutter free, and sufficiently lit.
- Vehicle doors should be closed during the raising and lowering cycles.
- Closely watch the vehicle and lift during the raising and lowering cycles.
- Do not operate the lift in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust. Power equipment can create sparks which may ignite flammables.
- Keep hands, tools, and other extremities from under carriage and moving parts.
- Never operate this lift with someone on it.
- Do not allow anyone on the lift or inside a raised vehicle.
- Keep children and bystanders away from work area. Do not let children operate or play on lift.
- Wear proper safety attire. Do not wear loose fitting clothing while operating lift. Long hair, jewelry and sleeves should be secured.
- Do not operate this lift if under the influence of drugs, alcohol, or medication. Operator must be alert at all times when using heavy lift equipment.
- Comply with all applicable accident prevention regulations.
- After positioning the vehicle, apply the parking brake.
- Use caution when removing or installing heavy vehicle components which may result in center-of-gravity displacement.
- Use this lift only for the work it is intended. Do not use this product for an application for which it was not designed. Misuse can lead to personal injury and/or property damage.



WARNING: Use this lift only in well ventilated areas. Carbon monoxide exhausted from running vehicle engines is a colorless, odorless fume that, if inhaled, can cause serious personal injury or death.



WARNING: People with pacemakers should consult their physician(s) before using this product. Operation of electrical equipment in close proximity to a heart pacemaker could cause interference or failure of the pacemaker.



WARNING: This product contains or produces a chemical known to the State of California to cause cancer and birth defects (or other reproductive harm). (California Health & Safety Code 25249.5 et seq.)

1.4 SAFETY INSTRUCTIONS FOR MAINTENANCE

- Maintenance or repair work should be done by authorized service personnel only.
- Work on the electrical equipment should be done by certified licensed electricians only.
- Ensure that ecologically harmful substances are disposed of in accordance with the appropriate regulations.
- To prevent the risk of damage, do not use high pressure / steam jet cleaners or caustic cleaning agents.
- Do not replace or override the safety devices.

1.5 RISKS



WARNING: Risks the personnel could encounter, due to an improper use of the lift, are described in this section.

CRUSHING RISK

During lowering of runways and vehicles, personnel must not be within the area covered by the lowering trajectory. The operator must be sure no one is in danger before operating the lift. Stay clear of the lift when lowering or raising vehicles. Keep hands and feet away from moving parts and especially points that could pinch. Keep your feet clear of the lift when raising and lowering vehicles.

BUMPING RISK

When the lift is stopped at relatively low working height, the risk of bumping against projecting parts increases. Always be aware of your surroundings and avoid bumping your head or body on the lift or the vehicle.

TILTING RISK

Use caution when lowering the lift and make sure the tracks stay level with the safety locks.

2-UNPACKING & SET-UP

Only skilled personnel who are familiar with the lift and this manual shall be allowed to carry out, lifting, handling, transport and unpacking operations.

2.1 DELIVERY AND CHECK OF PACKAGES

When the lift is delivered, carefully unpack the lift making sure all the parts have been included. Check for possible damages due to transport and storage; verify that what is specified in the confirmation of order is included. In case of damage in transit, the customer must immediately inform the carrier of the problem.


Remove the lift and all parts from delivery pallet and place on a clean, solid, flat surface. Packages must be opened paying attention not to cause damage to people (keep a safe distance when opening straps) and parts of the lift (be careful the objects do not drop from the package when opening.)

2.2 LIFTING AND HANDLING

When loading/unloading or transporting the equipment to the site, be sure to use suitable loading (e.g. cranes, trucks) and hoisting means. Be sure to hoist and transport the components securely so that they cannot drop, taking into consideration the package's size, weight, center of gravity, and its fragile parts.



LIFT AND HANDLE ONLY ONE PACKAGE AT A TIME



- 1. Power side post
- 2. The secondary post
- 3. Crossbeam
- 4. Platform assembly

- 5. Tool tray
- 6. Mobile kit
- 7. Oil dip tray
- 8. Power unit

3-SPECIFICATIONS

*Due to minor variances in the manufacturing process, dimensions in this manual may vary slightly from the finished product.

Specifications	SDPL-8KMS
Center Of Baseplates - Width	99-5/8"
Outside Of Baseplates - Width	109-13/16"
Outside Of Columns - Width	107-1/16"
Inside of Columns - Width	100-3/8"
Overall Width w/Motor	122-5/8"
Drive-Thru	90"
Between Runways	43-1/2"
Out To Out - Runways	80-7/8"
Length of Runway	160"
Width of Runway	18-11/16"
Total Length of Ramp	36-5/8"
Baseplate Dimensions	11-13/16" x 10-1/4"
Column Dimensions	3-3/8" x 6-5/16"
Center Of Baseplates - Length	158-1/16"
Outside Of Baseplates - Length	169-7/8"
Outside Of Columns - Length	164-3/8"
Inside Of Columns - Length	151-3/4"
Overall Length w/Ramps	201-7/16"
Lifting Height	4-1/2" - 76-3/4"
Overall Height	83-9/16"
Lifting Capacity	8,000 lb
Shipping Weight	1,770 lb




IMPORTANT: THE PROPERTIES INDICATED APPLY TO LIFTS RUNNING AT OPERATING TEMPERATURE.




IMPORTANT: COMPONENTS AND SPECIFICATIONS ARE SUBJECT TO CHANGE WITHOUT NOTICE.


DIMENSIONS - SIDE




DIMENSIONS - END



DIMENSIONS - OVERHEAD



SAFETY DEVICES OVERVIEW



No.	Name	Function
1-2	Mechanical safety locking unit	Catch the carriages in case of hydraulic failure
3	Manual locking release unit	Release mechanical safety lock manually.
4	Front wheel stop	Prevent vehicles from rolling off.

3.1 PARTS CHECK

Number	Name	QTY	Note
1	Main lifting platform	1	Package 1
2	Secondary lifting platform	1	
3	Power side post	1	
4	Post	3	
5	Power side crossbeam	1	
6	Secondary crossbeam	1	
7	Wheel retaining plate	2	
8	Mobile kit	4	
9	Drive-on ramp	2	
10	Tool tray	1	
11	Oil dip tray	3	
12	Oil hose package	1	
13	Protective covers	4	
14	Screws package	1	
14	Handle	1	
15	Steel cable	4	
16	User's Manual	1	
1	Power unit	1	Package 2

4-FLOOR REQUIREMENTS

4.1 SELECTING THE SITE AREA

1. Make sure that adequate space and height is available.
2. Check for ceiling clearance (lifting height plus vehicle height).
3. Check for clearance in front and rear of vehicle on lift.
4. Check for overhead garage door clearance.

4.2 FLOOR REQUIREMENTS

Do not use the lift on any asphalt surface. Make sure the lift is used on a dry, oil/grease free, flat level CONCRETE surface capable of supporting the weight of the lift, the vehicle being lifted, and any additional tools and equipment. The concrete floor surface should have a minimum thickness of 4". The concrete must have a minimum strength of 3,000 PSI, and should be aged at least 30 days prior to use. Do not use the lift on concrete expansion seams or on cracked, defective concrete.




WARNING: SPECIFICATIONS OF CONCRETE MUST BE ADHERED TO. FAILURE TO DO SO COULD CAUSE LIFT FAILURE RESULTING IN PERSONAL INJURY OR DEATH. THE FLOOR SHOULD BE A REINFORCED CONCRETE SLAB NOT LESS THAN 4" THICK WITH THE COMPRESSIVE STRENGTH OF THE CONCRETE NO LESS THAN 3,000 PSI.



DANGER: FOR CORRECT INSTALLATION OF THE LIFT, THE FLOOR MUST BE FLAT AND LEVEL. CHECK WITH STRAIGHT EDGE AND LEVEL. IF A FLOOR IS OF QUESTIONABLE SLOPE, CONSIDER A SURVEY OF THE SITE AND/OR THE POSSIBILITY OF POURING A NEW LEVEL CONCRETE SLAB.



IMPORTANT: NEW CONCRETE MUST BE ADEQUATELY CURED AT LEAST 30 DAYS MINIMUM. NO LIABILITY FOR ANY DAMAGES WILL BE ACCEPTED SHOULD YOU INSTALL THE LIFT ON AN UNSUITABLE FLOOR.



4.3 ANCHORING TIP SHEET

1. Use a concrete hammer drill with a carbide tip, solid drill bit the same diameter as the anchor, 3/4". (.775 to .787 inches diameter). **Do not use excessively worn bits or bits which have been incorrectly sharpened.**
2. Keep the drill perpendicular to the concrete while drilling.
3. Let the drill do the work. Do not apply excessive pressure. Lift the drill up and down occasionally to remove residue to reduce binding.
4. Drill the hole for anchor bolt completely through the concrete. If an error is made during the installation of these anchors, this will allow for the anchor bolt to be driven down into the ground, so that a new anchor may be installed in place (fig.1).
5. **Be sure to clean all dust from hole.** (fig. 2).
6. Place a flat washer and hex nut over threaded end of anchor, leaving approximately 1/4 inch of thread exposed above the nut (fig.3). Carefully tap anchor into the concrete until nut and flat washer are against base plate. Be sure to only tap the top of the anchor and not the nut. This could cause damage to the threads of the anchor.
7. Tighten the nut (fig. 4) to **85 ft-lbs** of torque.



DO NOT USE AN IMPACT WRENCH TO TIGHTEN ANCHORS!


5-INSTALLATION INSTRUCTIONS



IMPORTANT: BEFORE ATTEMPTING TO ASSEMBLE THIS LIFT TO MAKE SURE THAT THERE IS ENOUGH ROOM FOR ALL COMPONENTS. THE SAFETY ROD ASSEMBLY WILL TAKE UP ADDITIONAL SPACE WHILE BEING INSTALLED. KEEP THE FLOOR AREA CLEAR OF THE LIFT COMPONENTS UNTIL THEY ARE READY TO BE INSTALLED.


5.1 COLUMNS AND CROSSBARS

- 1) Locate the four columns and two crossbars.
- 2) Determine where the power unit will be located. (front driver or rear passenger side)
Place the column with the motor bracket in that location. The directions in this guide assume that the power unit will be placed in the front driver side position.
- 3) Lay columns down on their side and place the crossbeam into the columns. See figure below. Place the crossbeam all the way to the bottom. You will need to do this for both crossbeams. NOTE: Be sure to orient the cross bar to where the cable pulleys are facing inside the lift.



- 4) With the columns still on their sides, slide the safety lock ladders into each column and through the slot on each end of the crossbeam.


- 5) Once all lock ladders are in place, remove the upper locking hex nut. Leave the regular hex nut and flat washer on the ladder stud. Install the top caps onto the lock ladder stud and into each column. Place another washer and locking hex nut onto the lock ladder top cap. Before tightening make sure the bottom of the lock ladders are even with bottom of the column base. Be sure not to twist the lock ladders as you are tightening.



- 6) Using the supplied hardware hex bolt, locking washer, and washer secure the TOP CAPS onto the columns.
- 7) Stand the columns up right and raise both crossbeams to the same lock height so that you can comfortably work under the runways after they are installed.



5.2 RUNWAY INSTALLATION

- 1) Before installing runways, make sure that your column and Crossbeam assemblies are standing vertically and set in the proper locations. Also, remember that the ledge running down the side of the runways will always be oriented to the inside of the lift and the CYLINDER-SIDE RUNWAY goes on the power-unit side of the lift.



- 2) Place the ends of the cylinder runway onto the crossbeams and line up the 3/4" holes in the Crossbeam with the holes in the runway. Using the supplied hardware and installation plate to attach the runways to the crossbeams.


Repeat this step for the offside runway.



5.3 CABLE INSTALLATION

The cables for this lift are pre-installed and located in the CYLINDER SIDE runway.


Route the cables per the diagram below. Be sure that all cables are straight and not intertwined. All cables must be on the pulleys correctly to avoid any cable damage.



1. After installing the cables, be sure to inspect that all six cable retention bolts under the runway are installed. These bolts are in place to keep the cables on the pulleys in the event of cable slack.




2. Locate the 4 cable retention bolts on the crossbeams. Each cable retention bolt is located on each end of the cross bar under the pulleys. These will keep the cables routed securely around the pulleys even if the cables become slacked at any time.






IMPORTANT: Make sure that the SPINDLE RETENTION PLATES are properly installed so that the pins that go through the pulleys cannot fall out. There are 8 in total.



A

5.4 HYDRAULIC ASSEMBLY

1. Secure unit to column bracket using provided bolts, washers, lock nuts and nuts.
2. Remove the fitting with the plastic cap from the port on the power unit and connect the hydraulic supply hose to the power unit. (Teflon not required).
3. On the end of the cylinder hose, located under the runway. Remove the backing nut from the bulkhead fitting, insert fitting through the hole in the side of the runway and secure with backing nut.
4. Attach the straight end of the power unit hose to the bulkhead fitting. NOTE: It may be necessary to remove the hydraulic hose and re-install it to remove any twists in the hose.
5. Attach the 90-degree fitting to the power unit.



6. Fill the oil tank reservoir with hydraulic oil, approximately 1 - 2" below the fill cap. Fill the oil tank with a premium quality ISO-32 or AW-32 hydraulic oil. Ensure all hydraulic fittings are tight and not leaking.

5.5 FINAL ADJUSTMENTS



IMPORTANT: PRIOR TO PROCEEDING WITH THE FINAL ADJUSTMENTS PROCESS, PLEASE READ OPERATION INSTRUCTIONS IN SECTION 6.

- 1) Plug the hydraulic unit into a standard 110V-120V/60Hz AC outlet. Check to make sure that the cables are properly installed on their pulleys.
- 2) Press the power unit control button to raise the lift all the way to the top. Disengage the locks and lower the lift all the way down, holding the release lever for an additional 10-20 seconds to ensure that all air gets purged from the system. You will see the air purging back into the tank as the lift reaches the bottom.
- 3) Raise the lift and lower it onto one of the lock positions at a comfortable working height. Then you will need to use a level to check the platform by placing it on each runway and on each crossbeam. You will need to raise the lock ladders until the platform is level in all directions. This can be done by tightening the top nut on each lock ladder until the bubble is in the center of the vial. Once the adjustments have been made, tighten the lower nut of the lock ladder, up against the bottom of the top caps.
- 4) It is now time to adjust the lifting cables. Raise the lift until all (4) locks are no longer resting on the SAFETY LOCK LADDER. Using the same method as in step 3, tighten the cables until the platform is level. You can also check this by comparing the height from the top of the crossbeam to the top of the lock ladder opening. This will ensure that all (4) of the locks engage the lock ladders simultaneously.

NOTE: Steps 2, 3, and 4 are to be performed with no weight on the lift.

- 5) With the lift in the lowered position, install the APPROACH RAMPS on the side of the lift that the vehicle will be loaded from. On the opposite end, install the TIRE STOP PLATES. Carefully drive the vehicle onto the runways of the lift (it may not hurt to have a second person there to help guide you onto the lift). Once the vehicle is in place, chock the wheels using the methods you feel necessary, then remove the APPROACH RAMPS and install the other pair of TIRE STOP PLATES.
- 6) You are now ready to raise the vehicle. You may notice that the locks may slightly be "off" which is perfectly normal because for a short period of time, the cables will stretch as the lift gets used. You will need to adjust the cables accordingly so that all (4) locks continue to engage simultaneously.

6-OPERATION INSTRUCTIONS



IMPORTANT: ALWAYS CHOCK WHEELS AND SET PARKING BRAKE BEFORE LIFTING VEHICLE!



WARNING: LIFT OPERATION BY TRAINED AUTHORIZED PERSONNEL OVER 18 YEARS ONLY. APPLY THE PARKING BRAKE AFTER POSITIONING THE VEHICLE ON THE LIFT. DO NOT ALLOW ANYONE TO STAY IN LIFT AREA DURING RAISING AND LOWERING CYCLES. CLOSELY WATCH THE VEHICLE AND THE LIFT DURING RAISING AND LOWERING CYCLES. OBSERVE THE RATED LOAD CAPACITY AND LOAD DISTRIBUTION. DO NOT ALLOW ANYONE TO CLIMB ON LIFT OR STAY INSIDE VEHICLE. MAKE SURE THE VEHICLE DOORS ARE CLOSED DURING RAISING AND LOWERING CYCLES.


6.1 DEFECTS / MALFUNCTIONS



WARNING: IN CASE OF DEFECTS OR MALFUNCTIONS SUCH AS JERKY LIFT MOVEMENT OR DEFORMATION OF THE SUPERSTRUCTURE, SUPPORT OR LOWER THE LIFT IMMEDIATELY. CONTACT QUALIFIED SERVICE PERSONNEL.

6.2 CONTROLS

6.2.1 UP CONTROL



Once the up button is pressed, the lift moves up until the button is released or the limit stop is reached.

6.2.2 SAFETY LOCK CONTROL

1. Press and hold the lowering handle until the safety lock blocks are engaged to level safety stops on the columns.

6.2.3 LOWERING CONTROL

1. Press the up button enough to make the safety lock blocks disengage the safety stops on the columns. Pull and hold the safety lock release handle, and then press the lowering handle until the lift is completely lowered.

6.3.1 VEHICLE LOADING

1. Make sure front tire stop plates are in place and, position vehicle on lift runways by having another person guide you onto the runways.
2. Check for proper weight distribution (center of gravity should be evenly distributed between columns).
3. Set vehicle parking brake and chock tires to prevent vehicle movement.
4. Use caution before lifting pickup trucks, suv's and other vehicles. The individual axle weight capacity should not exceed 1/2 of lift capacity.
5. Make sure vehicle is neither front nor rear heavy.
6. Make sure to install all front and rear tire stop plates prior to raising the lift with a vehicle.

6.3.2 RAISING THE LIFT

1. Push the up button to raise lift until platform runways clear the floor.
2. Stop and check for vehicle movement and vehicle weight distribution. If secure raise to desired height.
3. Always lower the lift to the nearest lock position by pressing the lowering handle to relieve the hydraulic pressure and let the safety lock blocks set in a handle locked position.
4. Never work under a lift that is not in a level safety locked position.

6.3.3 LOWERING THE LIFT

1. Clear all obstacles from under lift and vehicle, and ensure only lift operator is in the lift area.
2. Stay clear of lift and raise the lift off the safety locks.
3. Pull safety lock release handle and press the lowering handle to begin descent.
4. Ensure lift is fully lowered, and remove tire stop plates prior to unloading the vehicle.
5. Make sure to install the ramps.
6. Having another person guide you, carefully unload the lift by driving off of the lift runways.



WARNING: PAY ATTENTION TO THE LOWERING SPEED OF ALL FOUR CORNERS. MAKE SURE THEY ARE MOVING DOWN AT THE SAME SPEED. STOP LOWERING THE LIFT BY RELEASING THE LOWERING LEVER ON THE POWER UNIT AND MOVING THE LOCK LEVER TO THE LOCK POSITION IF ANY CORNER STOPS MOVING OR IS SLOWER IN DESCENT. ALWAYS LOCK THE LIFT BEFORE GOING UNDER THE VEHICLE. NEVER ALLOW ANYONE TO GO UNDER THE LIFT WHEN RAISING OR LOWERING.



IMPORTANT: IT IS NORMAL FOR AN EMPTY LIFT TO LOWER SLOWLY - IT MAY BE NECESSARY TO ADD WEIGHT.



WARNING: THE OPERATOR MUST BE TRAINED AND AUTHORIZED TO OPERATE THE LIFT.


! WARNING: DO NOT GO UNDER VEHICLE UNDER ANY CIRCUMSTANCES WHILE VEHICLE IS BEING LIFTED OR LOWERED.

OPTIONAL CASTER KIT

i IMPORTANT: HITCH PIN AND HAIRPIN CLIP TO ATTACH CASTERS TO LIFT IN THE FOLLOWING STEPS.

1. Raise lift 2' - 3' high.
2. Place caster assemblies under crossbeams as shown. Secure with Hitchpin and Hairpin Clip.
3. Lower the lift and the columns will automatically raise off the floor.

NOTE: After using the caster kit, always check to ensure that all cables are still routed properly and aligned on the pulleys.



7-MAINTENANCE

! WARNING: DISCONNECT THE POWER BEFORE SERVICING THE LIFT.

i IMPORTANT: THE MAINTENANCE INTERVALS INDICATED BELOW APPLY TO AVERAGE WORKSHOP USE. THE LIFT SHOULD BE INSPECTED MORE FREQUENTLY FOR SEVERE USE APPLICATIONS.

7.1 MAINTENANCE SCHEDULE

It is important to keep the lift clean, dry, and well maintained by establishing a periodic preventive maintenance program to ensure trouble-free operation and long service life.

7.1.1 DAILY

1. Check safety lock audibly and visually while in operation.
2. Check safety latches for free movement and full engagement with the safety stops on the column.
3. Check hydraulic connections, and hoses for leakage.
4. Check that all cables are routed properly.
5. Check cables for damage, bends, cracks and any loose cable fittings.
6. Check for frayed cables in both raised and lowered position.
7. Check snap rings at all rollers and sheaves.
8. Check bolts, nuts, and screws and tighten if needed.
9. Check wiring & switches for damage.
10. Check floor for stress cracks near columns.
11. Check lubrication on cable sheaves and shafts.

7.1.2 WEEKLY

1. IF LIFT IS ANCHORED TO FLOOR - Check anchor bolts torque to 85 ft-lbs for the $\frac{3}{4}$ " anchor bolts. Do not use an impact wrench to tighten anchor bolts.
2. Check floor for stress cracks near column.
3. Check hydraulic oil level.
4. Check and tighten bolts, nuts, and screws.
5. Check all cable sheaves/assembly for free movement or excessive wear on cable sheave shaft.
6. Check for any locks and tighten as necessary.

7.1.3 YEARLY

1. Lubricate the cables sheave shaft by using grease gun at least once a year after the lift is in service.
2. Check for excessive wear of cable. Replace them if necessary.
3. Change the hydraulic fluid - good maintenance procedure makes it mandatory to keep hydraulic fluid clean. Operating temperature, type of service, contamination levels, filtration, and chemical composition of fluid should be considered. If operating in dusty environment shorter interval may be required.

7.1.4 SPECIAL MAINTENANCE TASKS

NOTE: The following items should only be performed by a trained maintenance expert:

1. Replacement of hydraulic hoses.
2. Replacement of cables and sheaves.
3. Replacement or rebuilding air and hydraulic cylinders as required.
4. Replacement or rebuilding pumps / motors as required.
5. Checking of hydraulic cylinder rod and rod end (threads) for deformation or damage.

7.2 MAINTENANCE BY OPERATOR

1. All moving parts have been lubricated at the factory and should be re-lubricated before the first use and at least once every six months to prevent damage.

7.2.1 HYDRAULIC SYSTEM

1. Check the fluid level with the lift fully lowered and add fluid as required. Use premium quality ISO-32 or AW-32 hydraulic oil.
2. Visually check all hydraulic hoses and connections for tightness before each use to ensure proper working condition.
3. Lightly oil the cylinder rod at least once every six months or when it becomes dry.

7.2.2 GREASING POINTS

Slide Tracks:

The slide tracks should be greased every six months (or more frequently in case of noise generation).

Lightly grease the slide tracks over their whole length using a brush.

7.2.3 OPERATION AND WEAR CHECKS

Examine lift for structural cracks, bends, or other signs of damage prior to each use. Do not use this product if worn or damaged.

7.2.4 LIFT STABILITY

1. Every six months check the nuts of all bolts for tightness.
2. Retighten them as required.

7.3 CLEANING



DANGER: DO NOT USE HIGH PRESSURE / STEAM JET CLEANERS OR CAUSTIC CLEANING AGENTS.

RISK OF DAMAGE!

- **PERIODICALLY WASH OFF AGGRESSIVE SUBSTANCES AND TREAT THE LIFT WITH OIL OR WAX SPRAY.**
- **REPAIR THE DAMAGE TO THE PAINTWORK IMMEDIATELY TO PREVENT CORROSION.**

8-TROUBLESHOOTING

MOTOR DOES NOT OPERATE

Failure of the motor to operate is normally caused by one of the following:

1. Breaker or fuse blown.
2. Faulty wiring connections; call electrician.
3. Defective up button; call electrician for service.

MOTOR FUNCTIONS BUT LIFT WILL NOT RISE

If the motor is functioning, but the lift will not rise do the following in the order given:

1. A piece of debris is under check valve. Push handle down and push the up button at the same time. Hold for 10-15 seconds. This should flush the system.
2. Check the clearance between the plunger valve of the lowering handle. There should be 1/16" clearance.
3. Remove the check valve cover and clean ball and seat.



WARNING: Failure to properly relieve pressure in the following step can cause injury to personnel. This lift uses ISO Grade 32 or other premium quality grade non-detergent hydraulic oil at a high hydraulic pressure. Be familiar with its toxicological properties, precautionary measures to take, and first aid measures as stated in the Safety Summary before performing any maintenance with the hydraulic system.

4. Oil level too low. Oil level should be just under the vent cap port when the lift is down. Relieve all hydraulic pressure and add oil as required.

OIL BLOWS OUT BREATHER OF POWER UNIT

If oil blows out of the breather of the power unit, take the following actions:

1. Oil reservoir overfilled. Relieve all pressure and siphon out hydraulic fluid until at a proper level.
2. Lift lowered too quickly while under a heavy load. Lower the lift slowly under heavy loads.

MOTOR HUMS AND WILL NOT RUN

If the motor hums but fails to run, take the following actions:

1. Lift overloaded. Remove excessive weight from lift.



WARNING: The voltages used in the lift can cause death or injury to personnel. In the following steps, make sure that a qualified electrician is used to perform maintenance.

2. Faulty wiring ***Call electrician***
3. Bad capacitor ***Call electrician***
4. Low voltage ***Call electrician***

LIFT JERKS GOING UP AND DOWN

1. If the lift jerks while going up and down, it is usually a sign of air in the hydraulic system. Raise lift all the way to top and return to floor. Repeat 4-6 times. Do not let this overheat power unit.

OIL LEAKS

Oil leaks at the power unit and cylinders are normally caused by the following:


1. Power unit: if the power unit leaks hydraulic oil around the tank-mounting flange check the oil level in the tank. The level should be two inches below the flange of the tank. A screwdriver can be used as a "dipstick".
2. Cylinder - Piston Rod: the rod seal of the cylinder is out. Rebuild or replace the cylinder.
3. Cylinder - Vent: the piston seal of the cylinder is out. Rebuild or replace the cylinder.

LIFT MAKES EXCESSIVE NOISE / VIBRATES


Excessive noise from the lift is normally caused by the following:

1. Cross beam ends are rubbing the columns. Readjustment needed.
2. Cylinder too tight, load lift half capacity and cycle up and down a few times to break in. Lift cylinder should quiet down with use. If not contact your Titan Lift Distributor to purchase an Oil Additive.
3. May have excessive wear on cable sheaves or shafts. Replace them.


9-DIAGRAMS/PARTS



No.	Code	Description	QTY
1	320204285	Motor - 115V (105V~120V)/230V(220~240)V-1.1KW -1PH-60/50HZ-2P	1
2	320902008	AC contactor - TMC-18-120V	1
3	330302008	Single way valve - YBZ-E2D3I1/1-03	1
4	330303015	Manual unloading valve - YBZ-E2D3I1/1-02-B	1
5	330303016	Manual unloading valve spool - YBZ-E2D3I1/1-02-C	1
6	330502015	Breather - YBZ-BT-G3/4-C	1
7	330405069	Oil tank - 10L	1
8	330403003	Oil sucking filter - YBZ-E2D3I1/1-10	1
9	330401013	Oil sucking tube - YBZ-SJYG350	1
10	330402006	Oil sucking tube - YBZ-E2D3I1/1-09	1
11	330301003	Cushion valve - HCF-Z1/4	1
12	202109071	Bolt - M8x80-GB70_1	2
13	204201004	Spring washer - XYGN-ZG-L350	2
14	330201904	Gear pump - YG-B	1
15	207101098	O seal ring - YH-D	1
16	201103001	Hex socket cylinder head screw - 6254E-A4-B12(6254A-A5-B12 50*50*4)	4
17	330600001	Connector - GJT-G1/4-9/16-18UNF	1
18	203102003	Nut - M10x1-GB6172_1	1
19	330305015	Throttle valve - YBZ-E2D3I1/1-11A	1
20	330105027	Hydraulic block - YLBZ-T1KK-3	1
21	201101100	Bolt - M6*50	1
22	330404013	Coupling - YBZ-E2.1Y1W14/1-01 (54mm)	1
23	320402011	Button - YW1B-M1E10 (UL)	1
24	330304014	Overflow valve - LHRV-08-42	1




No.	Code	Description	QTY
1	625000030	Oil cylinder - YG95-108-930-1300	1
2	330305009	Relief valve for cylinder - BDPF-G14-G14-I60	1
3	207103025	Composite washer - 13.7*20.00*1.50	1
4	624008209	Oil hose - L=890	1
5	615022014	Right angle connector - 612E-A8	1
6	624002150	Oil hose - L=1300	1
7	622034394	Power unit - 1.1KW	1





No.	Code	Description	QTY
1	201102026	Hex head full swivel bolt - M12X25-GB5783	4
2	204201006	Spring washer - D12-GB93	4
3	204101007	Flat washer - D12-GB95	4
4	203101012	Hex nut - M20-GB6170	3
5	204101011	Flat washer - D20-GB95	3
6	203103012	Hex locking nut - M20-GB889_1	1
7		Steel cable - P8-A20	1

No.	Code	Description	QTY
8	612901741	Safety ratchet - P8-A1-B3	1
9	202110005	Hex socket button head screw - M8X20-GB70_2	2
10	201102013	Hex head full swivel bolt - M8X30-GB5783	4
11	204201004	Spring washer - D8-GB93	4
12	204101005	Flat washer - D8-GB95	4
13	420040010	Anti-shock pad - 6254E-A23	4
14	203101005	Hex nut - M8-GB6170	4
15	202109030	Hex socket button head screw - M8X25-GB70_1	4
16	614901750	Portable kit - P8-A6-B1	1
17	420320050	Plastic wheel - 6445P-A1-B5-C5	1
18	204301005	Circlip - D16-GB894_1	2
19	410911664	Wheel shaft - P8-A6-B2	1
20	208107001	All directional wheel - WXL	1
21	615032044	Bolt - 64P-A5	1
22	615068650	Main post assembly - P8-A1	1




No.	Code	Description	QTY
1	615032025	Steel cable - L=6605	1
2	615032024	Steel cable - L=5015	1
3	615032027	Steel cable - L=10565	1
4	615032026	Steel cable - L=8990	1



No.	Code	Description	QTY
1	205101017	Bearing - 3020-SF-1X	4
2	410270101B	Shaft retaining block - 6435B-A3-B13	4
3	410270601	Adjustable post - 6435B-A3-B33	4
4	410300011	Spring washer - 6435M-A3-B32	4
5	410321303	Installation plate for drive-on ramp - 64P-A5-B8	4
6	612032042	Main swing rod assembly - 64P-A7-B3	2
7	410321611	Safety shaft - 64P-A7-B11	4
8	410321631	Safety block B1 - 64P-A7-B12	2
9	410321641	Safety block B2 - 64P-A7-B13	2
10	410321651	Adjustable plate B - 64P-A7-B14	4
11	410321663C	Protective cover A - 64P-A7-B15	2
12	410321673C	Protective cover B - 64P-A7-B16	2
13	420321010B	Sliding block - 64P-A7-B18	8
14	410321691	Torsional spring - 64P-A7-B19	1
15	410321701	Adjustable rod A - 64P-A7-B20	4
16	410321483B	Linkage rod - 64P-A7-B21	2
17	410321493	Connecting Bushing - 64P-A7-B22	2
18	410321521	Torsional spring - 64P-A7-B25	1
19	612032161	Release plate A - 64P2-A7-B6	2
20	204101006	Flat washer C - D10-GB95	16
21	204301004	Circlip - D15-GB894_1	2
22	204101009	Flat washer C - D16-GB95	16
23	204301007	Circlip - D20-GB894_2	8
24	206201001	Cotter pin - D2_5X30-GB91	4
25	204201003	Spring washer - D6-GB93	4
26	204101005	Flat washer C - D8-GB95	20
27	201101002	Hex bolt - M10X100-GB5780	4
28	202109044	Hex socket cylinder head screw - M10X35-GB70_1	16
29	202109075	Hex socket cylinder head screw - M10X80-GB70_1	4
30	203101007	Hex nut - M12-GB6170	4
31	202109053	Hex socket cylinder head screw - M12X35-GB70_1	4

No.	Code	Description	QTY
32	201102069	Hex head half swivel bolt - M16X110-GB5782	8
33	201102040	Hex head full swivel bolt - M16X30-GB5783	8
34	203103005	Hex locking nut - M6-GB889_1	8
35	202109022	Hex socket cylinder head screw - M6X25-GB70_1	5
36	202110013	Hex socket button head screw - M6X25-GB70_2	4
37	203103006	Hex locking nut - M8-GB889_1	8
38	202205006	Set-screw - M8X10-GB77	8
39	202110004	Hex socket button head screw - M8X12-GB70_2	10
40	201102011	Hex head full swivel bolt - M8X15-GB5783	8
41	202109031	Hex socket cylinder head screw - M8X30-GB70_1	2
42	614901743	Crossbeam A assembly - P8-A3-B1	1
43	614901746	Crossbeam B assembly - P8-A3-B2	1
44	410911649	Pulley shaft A - P8-A3-B3	4
45	612901719	Release plate B - P8-A3-B4	2
46	410911651	Pulley A - P8-A3-B5	4
47	410911653	Φ30 flat washer - P8-A3-B6	8
48	410911689	Front retaining plate - P8-A3-B7	2
49	410911654	Transfer bar - P8-A3-B8	1
50	410911652	Thicker washer - P8-A3-B10	16
51	611032165	Drive-on ramp - P8-A3-B11	2
52	612901720	Release handle assembly - P8-A3-B15	1
53	208105003B	Handle ball - SBQ-D32	1



No.	Code	Description	QTY
1	205101017	Bearing - 3020-SF-1X	4
2	205101099	Bearing - 40X50X18	2
3	205101100	Bearing - 40X50X30	1
4	410270101B	Shaft retaining block - 6435B-A3-B13	4
5	420270240	Guiding slider - 6435B-A4-B23	2
6	410270281	Cylinder shaft II - 6435B-A4-B26B	1
7	204201006	Spring washer - D12-GB93	4
8	204101007	Flat washer - D12-GB95	4
9	204101015	Flat washer - D30-GB95	1
10	204301014	Circlip - D40-GB894_2	1
11	206201011	Cotter pin - D4X50-GB91	1
12	205202055	JDB Bearing - JDB-303828	2
13	201101002	Hex head bolt - M10X100-GB5780	6
14	201102070	Hex head half swivel bolt - M12X100-GB5782	2
15	201102026	Hex head full swivel bolt - M12X25-GB5783	2
16	204104001	Washer - M8-D40XD8_4X2_5	2
17	208106001	Straight pressed oil cup - M8X1-JB9740_1	1

No.	Code	Description	QTY
18	202110004	Hex socket button head screw - M8X12-GB70_2	8
19	202111004	Hex socket flat head screw - M8X12-GB70_3	2
20	202110005	Hex socket button head screw - M8X20-GB70_2	2
21	410911651	Pulley A - P8-A3-B5	4
22	614901747	Main platform assembly - P8-A4-B1	1
23	410911663	Double slots pulley - P8-A4-B10	1
24	410911693	Support plate for cylinder - P8-A4-B11	1
25	410911665	Pulley B - P8-A4-B12	2
26	614901748	Secondary platform assembly - P8-A4-B2	1
27	410911657	Pulley shaft B - P8-A4-B3	4
28	410911658	Space sheath A - P8-A4-B4	2
29	410911659	Space sheath B - P8-A4-B5	2
30	614901749	Holder for pulley - P8-A4-B6	1
31	410911691	Guiding plate for oil cylinder - P8-A4-B7	1
32	410911661	Shaft - P8-A4-B8	1
33	410911662	Single slot pulley - P8-A4-B9	2
34	625000030	cylinder - YG90-102-930	1

[illegible]

WARRANTY REGISTRATION

In order to utilize the warranty on this Titan Lifts product, you must register your product with us. The simplest way to do this is to visit [TITANLIFTS.COM/WARRANTIES](https://titanlifts.com/warranties) and submit your information online. If you prefer to send your information through the mail, please fill out the form below and send this page to us at :

**Titan Lifts
PO Box 7069
Greenwood, IN 46142**

EQUIPMENT MODEL:	_____	SERIAL NUMBER:	_____
TYPE OF POWER UNIT:	_____	SERIAL NUMBER:	_____
DATE OF PURCHASE:	_____		
PLACE PURCHASED:	_____		
NAME:	_____		
STREET:	_____		
CITY, STATE, ZIP:	_____		
PHONE:	_____		
EMAIL:	_____		

☐ [OPT OUT OF PROMOTIONS](#)



In order to receive your warranty, return this card or visit [TITANLIFTS.COM/WARRANTIES](https://titanlifts.com/warranties) within 30 days.



LIMITED WARRANTY

The **Titan 2 Post lifts, 4 Post lifts and Bridge Jacks** are backed by a standard **1-year** replacement parts warranty and a **5-year** structural warranty from the date of purchase, to the original purchaser only. The **1-year** replacement parts warranty covers power units, hydraulic cylinders, and all other assembly components such as, but not limited to: turn plates, slip plates, cables, chains, valves, switches etc. This does not cover normal wear items such as, but not limited to: rubber lifting pads and nylon slide blocks. Titan Elite model lifts have been discontinued but still qualify under the same terms as shown above.

Titan Master Series, SL-6600 Scissor Lifts and PREMIER Series 2 Post Lifts are backed by a **2-year** replacement parts warranty and a **5-year** structural warranty from the date of purchase, to the original purchaser only. The **2-year** replacement parts warranty covers power units, hydraulic cylinders, and all other assembly components such as, but not limited to: valves, switches, capacitors etc. This does not cover normal wear items such as, but not limited to: rubber lifting pads, nylon slide blocks and rubber arm pads. **Titan Master Series** includes lifetime warranty on nylon slide blocks.

Titan MRL-6000 Scissor lifts are backed by a standard **1-year** replacement parts warranty and a **5-year** structural warranty from the date of purchase, to the original purchaser only. The **1-year** replacement parts warranty covers power units, hydraulic cylinders, and all other assembly components such as, but not limited to: valves, switches, capacitors etc. This does not cover normal wear items such as but not limited to rubber lifting pads.

Titan ROT-4500 Rotisseries are backed by a standard **1-year** replacement parts warranty from the date of purchase, to the original purchaser only. The **1-year** replacement parts warranty covers components such as, but not limited to: hydraulic cylinders, caster assemblies, bearings etc. This does not cover normal wear items such as, but not limited to, mounting adapters.

Titan Standard Duty and Heavy Duty motorcycle lifts are backed by a standard **1-year** replacement parts warranty from the date of purchase, to the original purchaser only. The **1-year** replacement parts warranty covers power units, hydraulic cylinders, pneumatic cylinders, and all other assembly components such as, but not limited to: cables, caster wheels, valves, switches, wheel vises etc. This does not cover normal wear items such as, but not limited to: rubber wheel vise pads.

Titan Light Duty motorcycle lifts are warranted for replacement parts only to the original purchaser for a period of **90 days** from the date of purchase. This **90 day** replacement parts warranty covers items such as, but not limited to: hydraulic cylinder, casters, pedal assemblies, wheel vises etc. This does not cover normal wear items such as, but not limited to: rubber wheel vise pads.

Titan Bulldog Moto Cradle Wheel Chock is warranted for replacement parts, only to the original purchaser, for a period of **2-years** from the date of purchase.

XL Tool by Titan Wheel Service Machines and Helper Arm Assemblies are backed by a standard **1-year** replacement parts warranty from the date of purchase, to the original purchaser only. The **1-year** replacement parts warranty covers internal boards, motors, pneumatic cylinders, and all other assembly components such as, but not limited to: cabinet, switches, valves, fittings etc. This does not cover normal wear items such as but not limited to: rubber pads, jaw protectors, air hoses, quick nut assemblies.

Titan shop equipment products and accessories are warranted for replacement parts only to the original purchaser for a period of **90 days** from the date of purchase. This **90 day** replacement parts warranty covers products such as but not limited to: EZ -Mover Jacks, Mini Jacks, tie down products, wheel service accessories, Bulldog Moto Cradle Wheel Chock accessories, dollies, stands, Multi-purpose Jacks, replacement power units purchased as stand alone units, etc.

Titan TJ1T, FJ2T, and FJ3T are warranted for replacement parts only to the original purchaser for a period of **1 year** from the date of purchase.

All non-serialized items will require proof of purchase in the form of a sales receipt from an authorized Titan Lifts dealer showing the date of purchase for any warranty consideration.

For **all** warranty considerations, Titan Marketing, LLC will supply replacement parts only during the warranty period. The original purchaser is responsible for all shipping, handling, and any labor charges incurred. Hydraulic/Pneumatic cylinders may qualify for exchange under warranty if reported within the first 30 days from date of sale. After the first 30 days from date of sale, a seal kit and installation instructions will be sent for cylinder repairs. All defective parts must be returned to Titan for inspection and examination. Any parts that are found to be defective will be replaced or repaired to proper working order. Other items not listed above may be considered general wear parts and therefore, will not be covered under warranty. These warranties **do not** extend to **defects** caused by ordinary wear, abuse, misuse, shipping damage, improper installation, voltage or lack of required maintenance. Titan Marketing, LLC is **not** to be held responsible for any **failure** that results from an accident, purchaser/operator abuse, neglect, or failure to operate products in accordance with instructions provided in the owner's manual(s) supplied. Damage caused by rain, excessive humidity, corrosive environments or other contaminants are not covered under warranty. **THESE WARRANTIES DO NOT EXTEND TO ANY COSMETIC DEFECT NOT INTERFERING WITH EQUIPMENT FUNCTIONALITY OR ANY INCIDENTAL, INDIRECT, OR CONSEQUENTIAL LOSS, DAMAGE, OR EXPENSE THAT MAY RESULT FROM ANY DEFECT, FAILURE OR MALFUNCTION OF A TITAN MARKETING LLC PRODUCT OR THE BREACH OR DELAY IN PERFORMANCE OF THE WARRANTY.**

P.O. Box 7069 • Greenwood, IN 46142 • Ph. 888-908-4826 • Fx. 317-215-2770 • www.titanlifts.com



WARNING



The warnings, precautions and instructions in this manual cannot cover all possible conditions and situations that may occur. The operator must understand that the operator must supply common sense and examine caution factors when using this product to determine safety in all circumstances being used.



TITAN MARKETING, LLC

PO Box 7069 Greenwood, IN 46142
1.888.908-4826 FAX (317) 215.2770
www.titanlifts.com

**Patent No.: US 8,104,588 B2
CA 2,729,670**

4/9/24