

Q. Illustration of installing the optional air line kits(Optional)

1. Install air line kit

1.1. Connect the air line fittings with $\phi 8 \times \phi 6$ black air line (The length of air line can be cut accordingly) **(Fig.48)**






Fig. 48



View c




c Tighten the oil hose of air line kit, oil hose and the air line of the lift air line system by tie kits and pass them through the plastic protecting hose



View d

Connect the adapter and coupler fitting of air line.



d Another side of the air line which shown in view d connect to the coupler fitting installed on the platform

1.2. Connecting air solenoid valve(Fig.49).




Fig. 49

2, Connecting air source, and operate the Jack with air pump.

Parts For Air line kits(optional)

Item	Code	Description	Qty
201-1	1061K090	Fast female connector	2
201-2	1061K091	Air hose connector	2
201-3	10430010	Washer	2
201-4	1061K092	Hex bolt	2
201-5	10420282	φ6*φ8*9600mm Air Line(only 414 414E 414A 414AE)	1
	10481085	φ6*φ8*12800mm Air Line(only 418 418A)	1
201-6	1061K094	90° fitting	1
201-7	1061K093	T- fitting	1
201-8	10420147	Straight fitting	1
201-9	1061K110	Straight fitting	1
201-10	10420146	Fitting	2
201-11	10520065A	Elastic air hose	2
201-12	10420213	Screw T-fitting	1
	1061K070A	Ties	2