

Remove Existing Pigtail From Lift (Do Not Operate Until Completed)

1.) Incoming Power

- a.) One hot to **terminal 6**
- b.) One hot to **terminal 2**
- c.) Ground to ground

2.) Motor

- a.) One hot to **terminal 8**
- b.) One hot to **terminal 4**

3.) Limit Switch

- a.) Cut ground off,
DON'T USE!
- b.) One hot to Up Button
terminal 4
- c.) One hot to **terminal 1**

4.) Jumpers

- a.) Jumper from Up Button
terminal 3 to **terminal 6**
- b.) Jumper from
terminal 2 to **terminal 0**

