

Stabilizer Bar & Carriage

LKSK



FEATURES

The Stabilizer Kit is not needed to remove or install a pickup box. When the pickup box is removed and remains on the lift, because of the front overhang, there will be some bounce if a technician is working on the bed while on the Lift. The stabilizer kit will eliminate the front bounce so the technician can bump, grind, weld and perform repairs without bounce.

The Stabilizer Kit can be installed on the lift within seconds. The Stabilizer Carriage straddles the legs of the lift and the Stabilizer bar slides into the Carriage for fast set up. Once the Stabilizer Carriage and Bar is in position, the Stabilizer bar is telescopic so the technician can adjust it into position, insert the safety pin and lower the box a slight amount to apply pressure between the bar and the box. This will eliminate frontend bounce. The box can be pushed around the shop while on the lift without the need of removing the Stabilizer Kit.

Stabilizer Bar & Carriage Photo: This will show exactly what comes in the Stabilizer Kit. It includes the Stabilizer Carriage, Stabilizer Bar, and the required hardware.

Stabilizer Bar Extended Photo: This will show the telescopic function of the Stabilizer Bar and the safety pin.

Stabilizer Bar Photo: This is a full view of the Stabilizer Bar

<https://www.youtube.com/watch?v=YCfEDhdarLg>



www.network1solutions.com